





## 1010PR



### Pin punch and Drift punch set - 10 pieces

Empty set : 831010PR

- Use a nail punch to remove and maintain your pin punch.

	Series	Content
	761	∅ 3 x 100 , ∅ 4 x 120 , ∅ 5 x 150
	763	∅ 3 x 120 , ∅ 6 x 120 , ∅ 8 x 120
	764	∅ 3 x 40 , ∅ 4 x 50 , ∅ 5 x 50 , ∅ 6 x 50