





1010PR



Pin punch and Drift punch set - 10 pieces

Empty set : 831010PR

- Use a nail punch to remove and maintain your pin punch.

	Series	Content
	761	Ø 3 x 100 , Ø 4 x 120 , Ø 5 x 150
	763	Ø 3 x 120 , Ø 6 x 120 , Ø 8 x 120
	764	Ø 3 x 40 , Ø 4 x 50 , Ø 5 x 50 , Ø 6 x 50