

9AT3F02

TDC Positioning Tool UNIVERSAL



- 9AT3-F01 required.
- Used for checking if the piston is at TDC position.

